


1:12 Scale R/C Rally Car Model Using Instruction




Caution: This model is not a toy, it is designed for user over 14 years of age.
Please use this instruction and the R/C system instruction at the same time.
The instruction is suitable for a type of model whose number is A939.


Sale parts view




Front wheel




Rear wheel




Before on the arm




Hem before arm



After the hem arm




Ball head block




Tie rod




Before the suspension bracket




Before the floor




Car seat can be adjusted




Car shell column




Shaft



After the car shell racks




Anti-collision parts



Tail



EVA anti-collision sponge



Blue car shell



Car shell silver




Underbody



C type seat




Steering arm




Rear seat



Rear suspension bracket




Before the shock absorber bracket seat




Front base plate positioning seat




Turning seat



Gear box



After the gear tooth




Differential planetary gear



Six angular wheel seat


Sale parts view

L959-24




Differential case

L959-25




Differential mechanism

L959-26




After the floor

L959-31




Front shock absorber

L959-32




Rear shock absorber

L959-33




390 motor

L959-34



14T gear motor

L959-35




Batteries (lithium iron battery)
7.4V 1500MA JST

L959-35-01




Batteries (lithium batteries)
7.4V 1500MA JST

L959-38




2.4G receiving box

L959-39-01




Charger (electron charge
+ balance charge)

L959-40




Server

L959-41




After the lower arm

L959-42




Differential cup

L959-43




Front axle

L959-44




Ball bearing (10X15X4)

L959-45




Oil bearing (5X9X3)

L959-46



Swing arm pin

L959-52



2.4G transmitter

L959-53




Countersunk head
machine screws 2X6

L959-54




Countersunk head
tapping screws 2.6X8

L959-55




Countersunk head
tapping screws 2.6X12

L959-56




Pan head tapping
screws 1.8X3

L959-57




Pan head tapping
screws 2.6X8

L959-58




Pan head tapping
screws 2.6X10

L959-59




Pan head tapping
screws 2.6X14

L959-60




Pan head tapping
screws 2.6X25

L959-61




Round head with dielectric
self tapping screws 2.6X4

L959-62



Round head with dielectric
self tapping screws 2.6X6


L959-63



Round head machine screws
2.5X6 with dielectric


Sale parts view

L959-64




Round head self-tapping screws 3 * 8 steps

L959-65




M4 Nut

L959-66




Car shell pin

L959-67



Shaft pin

L959-68




Differential pin

L959-69




Battery cover positioning shaft

L959-70




Motor fixed piece

L969-05




Rear suspension bracket

L969-07



Hand to


L979-08



Hand to

PRO Sale parts view

A939-P-01




Transmission shaft

L959-P-01




Battery *1
Lithium battery 7.4V
1800mA T type plug

L959-P-02




Brushless motor (2838)

L959-P-03



Brushless ESC

L959-P-04



Whole car bearing

A939-P-05



Brushless receiving plate